

PRO-LINE

1967 Ford® F-100 Heatwave® Edition

WRAP INSTALLATION INSTRUCTIONS


Congratulations on your purchase of the 1967 Ford® F-100 Heatwave® Livery for your short course truck. Please take a moment to read over these instructions for decal placement.

IMPORTANT: Peel off protective film before you begin to apply decals!



DECAL APPLICATION TIPS:

- For easy application and repositioning, use water in a spray bottle. Lightly mist the adhesive side of the decal. Squeegee out excess water once you are satisfied with decal placement.
- Start with number **1** and work your way through the decal sheets in numerical order for best results.



For an ultra realistic look, after decals are applied spray entire body with Pro-Line RC Body Paint - Matte Clear
SKU: 6324-02