

Water Decal Instructions:

The above are water decals. Do not force them off from the backing paper. Please follow these directions:



1. Make sure your hands are dry. Cut the decal down with scissors.
2. Put the decal in water for 2 mins to bring it to full absorption.



3. Carefully remove the decal from the backing paper and apply it on the corresponding position of the airframe (it would be helpful to wet the corresponding position of the airframe to adjust the decal)
4. Soak up the excess water with tissue, squeeze out air slowly, and wait for drying.
5. Remove the thin film (over the decals) 24 hours later.